

# Bissell®

## SPINWAVE CORDLESS

### 2240 SERIES

- EN BATTERY REMOVAL INSTRUCTIONS  
AR تعليمات إزالة البطارية  
BG ИНСТРУКЦИИ ЗА ОТСТРАНЯВАНЕ НА БАТЕРИЯТА  
BS UPUTSTVA ZA VAĐENJE BATERIJE  
CHS 電池拆卸說明  
CHT 電池拆卸指南  
CZ POKYNY K VYJMUTÍ BATERIE  
DE ANWEISUNGEN ZUR AKKUENTNAHME  
DK VEJLEDNING FOR FJERNELSE AF BATTERIET  
EL ΟΔΗΓΙΕΣ ΑΦΑΙΡΕΣΗΣ ΜΠΑΤΑΡΙΑΣ  
ES INSTRUCCIONES PARA RETIRAR LA BATERÍA  
ET PATAREI EEMALDAMISE JUHISED  
FI AKUN POISTO-OHJEET  
FR INSTRUCTIONS CONCERNANT LE RETRAIT DE LA BATTERIE  
HE הוראות להוצאת הסוללה  
HR UPUTE ZA UKLANJANJE BATERIJE  
HU AKKUMULÁTOR ELTÁVOLÍTÁSI ÚTMUTATÓ  
IT ISTRUZIONI PER LA RIMOZIONE DELLA BATTERIA  
KO 배터리 분리 방법  
LT AKUMULIATORIAUS IŠĖMIMO INSTRUKCIJA  
LV AKUMULATORA NOŅĒMŠANAS INSTRUKCIJAS  
MK УПАТСТВО ЗА ОТСТРАНУВАЊЕ НА БАТЕРИИТЕ  
ML ARAHAN MENGALIH KELUAR BATERI  
NL INSTRUCTIES VERWIJDEREN ACCU  
NO SLIK FJERNER DU BATTERIET  
PL INSTRUKCJA DEMONTAŻU AKUMULATORA  
PT INSTRUÇÕES DE REMOÇÃO DA BATERIA  
RO INSTRUCȚIUNI PENTRU SCOATEREA BATERIEI  
RU ИНСТРУКЦИИ ПО ИЗВЛЕЧЕНИЮ БАТАРЕИ  
SE INSTRUKTIONER BORTTAGNING AV BATTERIS  
SK POKYNY NA VYBRATIE BATÉRIE  
SL NAVODILA ZA ODSTRANITEV BATERIJE  
SR UPUTSTVO ZA UKLANJANJE BATERIJE  
TA பேட்டரியை அகற்றுவதற்கான அறிவுறுத்தல்கள்  
TH คำแนะนำการถอดแบตเตอรี่  
TR BATTERYA ÇIKARMA TALİMATLARI



